

Softwareinstallation

Installation unter Windows ME:

Die Installation geschieht weitgehend automatisch. Wird der Hardware-Assistent gestartet markieren Sie nach der Aufforderung "Was möchten Sie tun?" ⇒ "Automatisch nach dem besten Treiber suchen (Empfohlen)" und klicken dann auf ⇒ **Weiter** ⇒ **Fertig stellen**. Beantworten Sie die Frage nach dem Neustart mit ⇒ **Ja**. Ob die IEEE 1394-Karte ordnungsgemäß installiert wurde, können Sie unter **Start** ⇒ **Einstellungen** ⇒ **Systemsteuerung** ⇒ **System** ⇒ **Geräte-Manager** ⇒ **1394 Bus Controller** nachsehen. Dort muß der Eintrag "Texas Instruments OHCI-kompatibler IEEE 1394 Host Controller" ohne gelbes Ausrufezeichen vorhanden sein.

Installation unter Windows 98 SE:

Kurz nach dem Booten öffnet sich der **Hardware-Assistent** und sucht nach neuen Treibern für "Texas Instruments OHCI-kompatibler IEEE 1394 Host Controller". Klicken Sie auf ⇒ **Weiter**. Wählen Sie in der folgenden Maske ("Wie möchten Sie vorgehen?") "**Nach dem besten Treiber für das Gerät suchen**" ⇒ **Weiter** ⇒ **Weiter**. Markieren Sie "**Aktualisierten Treiber (empfohlen)**" ⇒ **Weiter** ⇒ **Weiter** ⇒ Windows kopiert nun die erforderlichen Treiberdateien. Wenn Sie dazu

aufgefordert werden, legen Sie die **Windows 98-CD** ein und klicken danach auf "**Ok**". (evtl. müssen Sie anschließend den Laufwerksbuchstaben für Ihr CD-ROM Laufwerk eingeben). Klicken Sie anschließend auf ⇒ **Fertig stellen**. Ob die IEEE 1394-Karte ordnungsgemäß installiert wurde, können Sie unter **Start** ⇒ **Einstellungen** ⇒ **Systemsteuerung** ⇒ **System** ⇒ **Geräte-Manager** ⇒ **1394 Bus Controller** nachsehen. Dort muß der Eintrag "Texas Instruments OHCI-kompatibler IEEE 1394 Host Controller" ohne gelbes Ausrufezeichen vorhanden sein.

Installation unter Windows 2000 Professional

Die Installation der Firewire-Karte erfolgt automatisch. Ob Windows die Schnittstellenkarte ordnungsgemäß installiert hat, können Sie unter **Start** ⇒ **Einstellungen** ⇒ **Systemsteuerung** ⇒ **System** ⇒ **Hardware** ⇒ **Geräte-Manager** ⇒ **IEEE-1394 Bus-Hostcontroller** nachsehen. Dort muss der Eintrag "Texas Instruments OHCI-konformer IEEE-1394-Hostcontroller" ohne gelbes Ausrufezeichen vorhanden sein.

Hinweis zum internen Anschluss für Karten mit 4 Anschlüssen

Wenn Sie den internen Firewire-Anschluss (CN4) benutzen, darf der erste externe (CN1) nicht benutzt werden.

Quick Reference IEEE 1394 FireWire Card

Software installation

Installation under Windows ME:

The card gets installed almost automatically. When Windows is starting the add new hardware wizard and asks "What would you like to do?" mark ⇒ "Automatic search for a better driver (Recommended)" and then click on ⇒ **Next** ⇒ **Finish**. Answer the question about the restart with ⇒ **Yes**. You can check if the IEEE 1394 card has been installed properly. Click ⇒ **Start** ⇒ **Settings** ⇒ **Control Panel** ⇒ **System** ⇒ **Device Manager** ⇒ **1394 Bus Controller**. There must be an entry "Texas Instruments OHCI Compliant IEEE 1394 Host Controller" without a yellow exclamation mark.

Installation under Windows 98 SE:

Shortly after booting the system is starting the **Add New Hardware Wizard** and searches for new drivers for "Texas Instruments OHCI Compliant IEEE 1394 Host Controller". Please click on ⇒ **Next**. In the following window ("What do you want Windows to do?") select "**Search for the best driver for your device**" ⇒ **Next** ⇒ **Next**. Mark "**The updated driver (Recommended)**" ⇒ **Next** ⇒ **Next**. Windows is now copying the necessary

drivers. Insert the **Windows 98 CD-ROM** if needed and then click on "**Ok**" (Possibly you must then enter another drive letter for your CD-ROM drive). Afterwards please click on ⇒ **Finish**. You can check if the IEEE 1394 card has been installed properly. Click ⇒ **Start** ⇒ **Settings** ⇒ **Control Panel** ⇒ **System** ⇒ **Device Manager** ⇒ **1394 Bus Controller**. There must be an entry "Texas Instruments OHCI Compliant IEEE 1394 Host Controller" without a yellow exclamation mark.

Installation under Windows 2000 Professional

The Firewire card gets installed automatically. You can check if Windows has installed the interface card properly. Click ⇒ **Start** ⇒ **Settings** ⇒ **Control Panel** ⇒ **System** ⇒ **Hardware** ⇒ **Device Manager** ⇒ **IEEE 1394 Bus host controllers**. There must be an entry "Texas Instruments OHCI Compliant IEEE 1394 Host Controller" without a yellow exclamation mark.

Hints for the internal connector for cards with 4 connectors

When you are using the internal Firewire connector (CN4), you must not use the first external (CN1) one.